

FLAMEPROOF 8/16 CHANNEL DATA LOGGERS



FLP 16 CHANNEL DATA LOGGER



FLP 8 CHANNEL DATA LOGGER

FLAMEPROOF 8/16 Channel Universal Input Data Loggers can be configured to take inputs of RTD Pt-100 Sensors (Temperature), Pressure (4-20 mA), Humidity (4-20 mA), Temperature from Transmitters (4-20 mA), Any thermocouples, Voltage or Current (mA) Signals. Data Loggers can be programmed from the front keys to print the data of all 8/16 Channels at any time interval. This means that the print time between successive printouts is user programmable from 5 secs to 9999 secs. The printout includes the date, time, channel no. & its value. Additional features include universal input selectable from front key, i.e., each channel can be independently configured for any kind of input. Thus, a single instrument can be used to record temperatures, pressure, vacuum, flow, pH, conductivity on different channels of the same instrument. The instruments have a RS232 /RS485 Computer communication port & come with the trusted software's with Online Tabular View, Data Graphing & Excel Sheet Reporting.

ACE INSTRUMENTS

(An ISO 9001-2008 Certified Company)

Plot No.77, Shaktipuram, Industrial Estate Kukatpally, Prashantinagar

Hyderabad – 500072, INDIA. Phones: +91-40-23078848, 23078849

Email: sales@alwaysace.com | Website: www.alwaysace.com

