FLAMEPROOF DIGITAL VACUUM INDICATOR



Flameproof Digital Vacuum Indicators manufactured by Ace Instruments are state of the art vacuum readoutinstruments with an built -in stainless steel diaphragm sensor & housed in an explosion proof/flameproof enclosure suitable for operation in hazardous areas. These instruments find extensive applications in online continuous vacuum measurement at vacuum pumps, distillation columns, reactors, vacuum lines, furnaces, etc. in hazardous (Ex-proof) areas with instruments housed in Flameproof enclosures certified by Central Institute of Mining & Fuel Research(CIMFR), Dhanbad, India, an authority with international approvals & processes. Sensors used are built -in imported Stainless Steel with S.S. 316 wetted parts & diaphragm with 1/2" BSP Male threading connection.

Specifications:

Manufacturer : ACE Instruments

Models : AI-VAC F

Vacuum Measuring

Range

: 0 – 760 mm. Hg. / **760 - 0 Torr Absolute**

Sensor Type : Built - in Stainless Steel sensor with SS316 wetted parts

Analog Output : 4 - 20 mA

Display : 4 - Digits 7 segment. 0.5" High Red L.E.D

Display Resolution : 1 mm. Hg/1 Torr

Accuracy : $\pm 0.5\%$ F.S.

Power : 24 Volts DC, 500mA

Enclosure : Flameproof Weatherproof Enclosure in Aluminium LM 6 with certificate issued

from Central Institute of Mining & Fuel Research (CIMFR) for use in Hazardours

Areas including Gas Group Areas I, II, IIA & IIB

Warranty : 12 Months Manufacturer Warranty

ACE INSTRUMENTS

(An ISO 9001-2015 Certified Company) 5-5-35/205A. Shaktipuram . Industrial Estate Kukatpally. Prashanti

Plot No.5-5-35/205A, Shaktipuram , Industrial Estate Kukatpally, Prashantinagar, Hyderabad – 500018.

Phones: +91-40-23078848, 23078849
Email: sales@acefirst.com Website: www.acefirst.com

