FLAMEPROOF HUMIDITY & TEMPERATURE INDICATOR WITH TRANSMITTER



ACE INSTRUMENTS make Flameproof Humidity& Temperature Indicator simultaneously measures % RH & Temperature in hazardous area applications. The flameproof display unit accepts 2 Analog Inputs of 4-20mA received from external flameproof humi-temp transmitter. The External Humi-Temp Transmitter Model AI-RHT-D-EX gives 2 Analog Outputs one each for temperature & humidity . Optional RS 485 Modbus Communication is also available as an additional feature . The instrument finds immense usage in pharmaceuticals , petrochemicals, bulk, drugs, chemicals, warehouses, pharma clean rooms & other allied applications.

Specifications	
Manufacturer	ACE Instruments
Model	Transmitter: AI-RHT-D-EX, Display Unit: AI-RHTA-FLP-LCD
Sensor Type	Polymer sensing for Temperature Capacitive polymer sensing for Relative humidity
Range	1) 0.0 to +60.0 Deg.C typical for Temperature Standard (Speak to speak to Factory team for any other ranges) 2) 0.0 to 100.0%R.H. for Relative humidity
Communication	Optional RS 485 Modbus Protocol Communication for BMS (Speak to Ace Instruments Team for details)
Resolution	Fixed 0.1 for both Temperature & Relative humidity
Accuracy	1) \pm 0.5 Deg.C for Temperature 2) \pm 1.8% for 10 to 95% RH for Relative humidity +/-2% for all other ranges
Display	2 - line 128 x 64 Graphic LCD Display with MIN/ MAX Feature.
Supply Voltage	24VDC / 300mA
Enclosure	Flameproof / Weatherproof Aluminium LM-6 Body Certified by Central Institute of Fuel & Mining Research (CIMFR), Dhanbad for use in Gas Group Areas I, II, IIA & IIB
Sensor Housing	Standard Stainless Steel Perforated Integrated Housing Pipe / Optional Stainless Steel External Perforated Housing for Remote Room Monitoring Wired Sensor (speak to Factory for this Option)
Output	2 x 4-20 mA outputs, 1 each for Temp and Humidity.
Dimension	Instrument Enclosure : 220 x 210 x 50 mm (H x W x D) , Transmitter: 120 x 120 x 90 (L x B x D) mm

ACE INSTRUMENTS

12 Months Manufacturer Warranty

Warranty

(AN ISO 9001 - 2015 COMPANY)
Plot No.5-5-35/205A, Shaktipuram , Industrial Estate Kukatpally,
Prashantinagar, Hyderabad – 500018.
Phones: +91-40-23078848, 23078849
Email: sales@acefirst.com Website: www.acefirst.com

